



Installation Instructions

- 1) Preparation
 - a) Receiving your cabinet
 - i) If you see any damage or problems, call us right away. Any damage must be reported within 24 hours of receiving your cabinet. Otherwise, find the enclosed hardware and put it aside.
 - b) Hardware supplied and tools required
 - i) Included with each cabinet are:
 - (1) Four 3/8"x3" Stainless Steel bolts, washers and nylock nuts.
 - ii) Tools Needed:
 - (1) Masking Tape
 - (2) A tube of silicone
 - (3) A Drill with 3/8" bit
 - (4) A 9/16" Wrench and/or socket
 - (5) A Phillips head screwdriver
- 2) Installation
 - a) Place Cabinet into Vehicle
 - i) Use masking tape to cover the lower plastic trim to protect from scratches as the cabinet is put into the vehicle. You may also remove the plastic trim and re-install it after cabinet installation
 - ii) Once cabinet is in vehicle, slowly close the tailgate and ensure there is adequate clearance.
 - iii) Place cabinet in desired position. Examine the underside of the vehicle for unobstructed drilling locations.
 - b) Drilling the holes
 - i) From underneath the vehicle, drill 4 holes up through the floor and cabinet (one in each corner of cabinet)
 - c) Fastening the cabinet to the vehicle
 - i) Slide one of the supplied bolts through each hole from the top down.
 - ii) From underneath the truck, place a bead of silicone around each hole
 - iii) Add washer, then nut. Tighten each bolt evenly to keep cabinet level.
 - iv) Your cabinet is now fully installed
 - d) Notes:
 - i) If you ordered a cabinet with a bottom drawer, it may be necessary to remove it before installation